

INSTALLATION INSTRUCTIONS - SM CORNER GUARDS

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING CORNER GUARDS. MATERIAL MUST BE STORED, INSTALLED, AND USED IN ENVIRONMENTALLY CONTROLLED CONDITIONS.

THE WALL SURFACE THAT THE CORNER GUARDS ARE TO BE APPLIED TO MUST BE DRY AND FREE OF DIRT, DUST, OIL, LOOSE PAINT, WAX, AND GREASE.

ADHESIVE INSTALLATION:

- APPLY A BEAD OF ADH-50 ADHESIVE IN A ZIG ZAG PATTERN OVER THE BACK OF EACH WING OF THE CORNER GUARD.
- POSITION CORNER GUARD ON THE WALL AND APPLY PRESSURE UNTIL A TIGHT FIT IS ACHIEVED.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE CORNER GUARD

SCREW-ON INSTALLATION:

- ATTACH CORNER GUARD TO WALL WITH NECESSARY HARDWARE. STANDARD SPACING IS 3" FROM EACH END AND SPACED EVENLY NOT TO EXCEED 36" O.C.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE CORNER GUARD.

