

## INSTALLATION INSTRUCTIONS - FM CORNER GUARDS

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING CORNER GUARDS. MATERIAL MUST BE STORED, INSTALLED, AND USED IN ENVIRONMENTALLY CONTROLLED CONDITIONS.

- BEFORE INSTALLATION OF DRYWALL, ATTACH THE FLUSH MOUNT CORNER GUARD TO THE CORNER STUDS.
- INSTALL DRYWALL OVER THE CORNER GUARD MOUNTING FLANGE. USE J-CANNEL DRYWALL TRIM TO FINISH THE EDGE OF THE DRYWALL.
- REMOVE PROTECTIVE FILM FROM THE CORNER GUARD

