

## INSTALLATION INSTRUCTIONS - S/S KICK PLATES

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING KICK PLATES. MATERIAL MUST BE STORED, INSTALLED, AND USED IN ENVIRONMENTALLY CONTROLLED CONDITIONS.

THE DOOR SURFACE THAT THE KICK PLATES ARE TO BE APPLIED TO MUST BE DRY AND FREE OF DIRT, DUST, OIL, LOOSE PAINT, WAX, AND GREASE.

### ADHESIVE INSTALLATION:

- APPLY A BEAD OF ADH-50 ADHESIVE IN A ZIG ZAG PATTERN OVER THE BACK OF EACH SURFACE OF THE KICK PLATE.
- PROPERLY POSITION THE KICK PLATE ON THE DOOR AND APPLY PRESSURE UNTIL A TIGHT FIT IS ACHIEVED.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE KICK PLATE.

### SCREW-ON INSTALLATION:

- ATTACH KICK PLATE TO DOOR WITH NECESSARY HARDWARE. SPECIFY DRILLING REQUIREMENTS WHEN ORDERING.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE KICK PLATE.

