

SUPER DUTY WALL PROTECTION

Super Duty wall guards, corner guards, end wall guards, kick plates, handrails, and wall panels do not require special cleaning or maintenance.

Clean the Super Duty coating with a stiff brush, water, and automotive soap. Scrub well. If extremely soiled, clean with calcium, lime, and rust (CLR) cleaner. Once dry, you can also apply a non-silicone, non-oil protectant to keep a clean finish.